

WATERPROOF WOOD FLOORING - FLOATING INSTALLATION INSTRUCTIONS

When properly installed in accordance with Shaw's published installation instructions, this product will not swell, cup, or crack due to exposure to water from topical spills or moisture from the sub-floor when exposed to such conditions. This product is not designed to withstand submersion from standing water or flooding.

READ THESE INSTRUCTIONS THOROUGHLY BEFORE BEGINNING INSTALLATION. If the following instructions leave any unanswered questions or if additional information is required, please call Shaw Technical Support at 1-800-441-7429. This flooring is a natural wood product on a solid polymer core, which has natural variations in color, texture, and sheen/gloss. For best visual effect, install planks working from several cartons.

INSTALLER/OWNER RESPONSIBILITY

- We urge you, as the final inspector to inspect for proper color, finish, style, and quality PRIOR to installation. Verify that the flooring is the correct material. Care should be taken at this time to remove or repair particular characteristics you do not desire. Manufacturer declines responsibility for any costs incurred when plank(s) with visible defects have been installed.
- The use of stain, filler, or putty stick for the correction of minor defects during installation should be accepted as normal procedure. 5% cutting allowance, depending on layout, must be added to the actual square footage amount needed.

NOTE: Waterproof Wood Flooring may be installed with a direct glue-down method on approved wood (or) concrete substrates on or above grade only. For below grade installations, use the floating installation method.

Follow Shaw T-180 adhesive label application instructions. Install flooring into wet adhesive to achieve a permanent bond. Maintain 1/4" (6.35 mm) perimeter expansion space. Refer to adhesive label for moisture limits of the adhesive. Roll flooring immediately after installation with a 100 lbs. 3-section roller.

Use only Shaw approved adhesives. Please consult with the adhesive manufacturer (or) contact Shaw Technical Support at 1.800.471.7429 directly to determine if the selected adhesive is suitable for use with this material.

- Do not install Waterproof Wood Flooring as a floating floor where it will be exposed to temperatures greater than 140° F. In areas where the floor may be exposed to direct, intense sunlight resulting in excessive heat to the floor, use the full spread glue down method and Shaw T-180 or comparable adhesive. Avoid exposure to direct sunlight for prolonged periods, doing so may result in discoloration. During peak sunlight hours, the use of the drapes or blinds is recommended.

PRE-INSTALLATION JOBSITE REQUIREMENTS

It is the installer/owners' responsibility to ensure that the jobsite conditions and jobsite subfloor are environmentally and structurally acceptable prior to the installation of any hardwood flooring. The manufacturer declines any responsibility for failures or deficiencies of hardwood flooring resulting from or related to sub-floor, sub-surface, or job-site environmental conditions. All substrates must be clean, flat, dry, and structurally sound.

- Flooring should be one of the last items installed in any new construction or remodel project.
- Install flooring after cabinets have been installed to prevent damage to the flooring.

Room temperature and humidity of installation areas should be consistent with normal, year-round living conditions for at least one week before installation of flooring. Maintaining an optimum yearly room temperature of 70° F and a humidity range of 35- 55% is recommended.

CAUTION: WOOD DUST

The International Agency for Research on Cancer has classified wood dust as a nasal carcinogen. The sawing, sanding, and/ or machining of wood products can produce wood dust that can cause respiratory, eye, and skin irritations. Equipment should be equipped with a dust collector to reduce airborne wood dust. Wear an appropriate NIOSH designated dust mask to reduce exposure to airborne wood dust. Avoid contact with eyes and skin. In case of irritation, flush eyes or skin with water for at least 15 minutes. In cases of severe irritation; seek immediate medical attention. *For further technical or installation questions or to request a Product Specification Data Sheet contact*

the manufacturer 1-800-441-7429.

WARNING: Drilling, sawing sanding or machining wood products can expose you to wood dust a substance known to the State of California to cause cancer. Avoid inhaling wood dust or use a dust mask or other safeguards for personal protection. For more information go to www.P65Warnings.ca.gov/wood.

PRE-INSTALLATION SUBFLOOR REQUIREMENTS

Note: All subfloors must be flat to within 3/16" in 10' or 1/8" in 6'.

WOOD SUBFLOORS

- Do not install material over wood subfloors that lay directly on concrete or over dimensional lumber or plywood used over concrete. Refer to ASTM F1482 for panel underlayment recommendations.
- Do not apply sheet plastic over wood subfloors.
- Basements and crawl spaces must be dry. Use of a 6 mil black polyethylene is required to cover 100% of the crawl space earth. Crawl space clearance from ground to underside of joist is to be no less than 18" and perimeter vent spacing should be equal to 1.5% of the total square footage of the crawl space area to provide cross ventilation. Where necessary, local regulations prevail.
- All other subfloors - Plywood, OSB, particleboard, chipboard, wafer board, etc. must be structurally sound and must be installed following their manufacturer's recommendations. Local building codes may only establish minimum requirements of the flooring system and may not provide adequate rigidity and support for proper installation and performance. If needed add an additional layer of APA rated underlayment, fasten and secure according to the underlayment manufacturer's recommendations.
- Hardwood flooring is not recommended directly over fire-retardant treated plywood or preservative treated plywood. An additional layer of APA rated 1/4" thick underlayment should be installed.

CONCRETE SUBFLOORS

- Floors shall be smooth, permanently dry, clean, and free all foreign material such as dust, wax, solvents, paint, grease, oils, and old adhesive residue. The surface must be hard and dense, and free from powder or flaking.
- New concrete slabs must be dry. Maximum moisture level per CaCl test method is 5 lbs. per 1000 in 24 hr. Maximum level for ASTM 2170 In-situ Relative humidity test method - 85%.
- Do not install over concrete with a history of high moisture or hydrostatic conditions.
- Ph level of concrete should be between 7-10.
- The final responsibility for determining if the concrete is dry enough for installation of the flooring lies with the floor covering installer.

WARNING! DO NOT SAND, DRY SWEEP, DRY SCRAPE, DRILL, SAW, BEADBLAST OR MECHANICALLY CHIP OR PULVERIZE EXISTING RESILIENT FLOORING, BACKING, LINING FELT, ASPHALTIC "CUTBACK" ADHESIVES OR OTHER ADHESIVES.

These products may contain either asbestos fibers and/or crystalline silica. Avoid creating dust. Inhalation of such dust is a cancer and respiratory tract hazard. Smoking by individuals exposed to asbestos fibers greatly increases the risk of serious bodily harm. Unless positively certain that the product is a non-asbestos-containing material, you must presume it contains asbestos. Regulations may require that the material be tested to determine asbestos content and may govern the removal and disposal of material. See current edition of the Resilient Floor Covering Institute (RFCI) publication Recommended Work Practices for Removal of Resilient Floor Coverings for detailed information and instructions on removing all resilient covering structures. For current information go to www.rfci.com.

EXISTING FLOOR COVERINGS

- Waterproof Wood Flooring can be installed over most existing hard-surface floor coverings provided that the existing floor surface is clean, flat dry and structurally sound.
- Existing sheet vinyl floors should not be heavily cushioned and not exceed more than one layer in thickness.
- Installation is **NOT** allowed over any type of carpet.
- **Do NOT** install over wood subfloor or wood floors adhered to concrete.
- Ceramic tile.
- Never use solvents or citrus adhesive removers to remove old adhesive residue. Solvent residue left in and on the subfloor may affect the new floor covering.

STARTING YOUR INSTALLATION

- Because houses and buildings, as well as adjacent hardwood or laminate floors, expand and contract, Shaw recommends leaving a ¼" expansion gap between the perimeter walls and any adjacent hardwood floor.

Note: Larger rooms require additional expansion space. Add 1/16" to the width of the expansion space for every 3' the room extends beyond 25'.

Work from several open boxes of flooring and "dry lay" the floor before permanently laying the floor. This will allow you to select varying textures, colors, and sheens, and to arrange them in a harmonious pattern. Remember, it is the installer's responsibility to determine the expectations of what the finished floor will look like with the end user first and then to cull out pieces that do not meet those expectations.

Begin installation next to an outside wall. This is usually the straightest and best reference for establishing a straight working line. Establish this line by measuring an equal distance from the wall at both ends and snapping a chalk line. The distance you measure from the wall should be the width of a plank. You may need to scribe cut the first row of planks to match the wall in order to make a straight working line if the wall is out of straight.

You may want to position a few rows before starting installation to confirm your layout decision and working line. When laying flooring, stagger end joints from row to row by at least 8" (20 cm) for planks. Use the cut-off end to begin the next row when cutting the last plank in a row to fit. If cut-off end is less than 8", discard it and instead cut a new plank at a random length (at least 8" in length) and use it to start the next row. Always begin each row from the same side of the room.

INSTALLATION INSTRUCTIONS

These installation guidelines apply to the Waterproof Wood Flooring product. All instructions and recommendations should be followed for a successful installation.

Tools: Tape Measure, Utility Knife, Jigsaw, Tapping Block or Rubber Mallet, Pull Bar, ¼" Spacers, T-Square, Safety Glasses, Broom or Vacuum and, if necessary, tools for subfloor repair.

- Waterproof Wood Flooring is an interior product and must be stored/installed in a temperature-controlled interior environment, maintained between 55 and 85 degrees F or 13°-29°C.
- Excessive moisture in the subfloor could promote mold, mildew, and other moisture related issues that will contribute to an unhealthy indoor environment. Shaw is not responsible for damages related to these moisture issues. Shaw recommends a 6 mil polyfilm when installing over concrete subfloors.
- Flexible silicone caulking should be used around the perimeter of the installation in areas being exposed to excessive topical moisture.
- Flooring should be installed after all other trades have completed work that could damage the flooring.
- Use cementitious patching and leveling compounds that meet or exceed maximum moisture level and pH requirements. Use of gypsum based patching and/or leveling compounds, which contain Portland or high alumina cement and meet or exceed the compressive strength of 3,000 psi are acceptable.
- Inspect all planks for damage prior to installation. If you have any concerns about the product fit or finish, call Shaw Technical Support at 1-800-441-7429. Claims>Returns will not be accepted for any flooring that has been cut to size and/or installed.

Radiant Heat: Waterproof Wood Flooring can be installed over radiant heat using either the floating or glue down method. When gluing floor use Shaw T-180 or comparable adhesive over manufacturer's recommended substrate. Radiant heat systems must have a minimum of 1/2" separation from the product. Maximum operating temperature should never exceed 85°F (30°C). Use of an infloor temperature sensor is recommended to avoid overheating.

- **Turn the heat off for 24 hours before, during and 24 hours after installation when installing over radiant heated subfloors.**
- Failure to turn the heat off may result in significantly shortened working time of the adhesive.
- Floor temperature must not exceed **85°F (30°C)**.
- Once the installation has been completed, the heating system should be turned on and increased gradually (5 degree increments) until returning to normal operating conditions.
- Failure to strictly follow adhesive manufacturer's guidelines may result in failure and void the warranty.

Warning: Electric heating mats that are not embedded into the subfloor are not recommended for use underneath Waterproof Wood Flooring.

Installation: Waterproof Wood Flooring is engineered to be installed utilizing the floating method. Do not install cabinets or fixed objects atop the flooring. Proper expansion space is required. Undercut all doorjamb. Do not fasten wall moldings

and or transition strips to the floor and planks.

- Check groove on plank to make sure it is clean and free of debris.
- 1. Before you start with the installation, it is important to determine the layout of the flooring. Proper planning and layout will prevent having narrow plank widths at wall junctures or very short length pieces at the end of rows.
- 2. As with all plank products, install the planks parallel to the longest exterior wall.
- 3. Determine if the starter row will need to be cut. If the first row of planks does not need to be trimmed in width, it will be necessary to cut off the unsupported tongue so that a clean, solid edge shows towards the wall.
- 4. Installation of the product must start from the left side of the room, working to the right when working in front of the planks or facing the starting wall. Use spacers along the walls to maintain proper expansion space (1/4") and align the first plank.
- 5. Install the second plank in the row by aligning and dropping the end tongue over the end groove of the first plank. Apply light pressure to join the two planks together.
- 6. If needed, use a rubber mallet to fully engage the short side of the plank by lightly tapping the plank to engage and sit flush with the adjacent plank. Maintain an expansion gap of approximately 1/4" from the wall. Repeat this process to complete the first row.
- 7. Start the second row by cutting a plank to the desired length. Keep in mind that the plank must not be shorter than 6" (15cm) to achieve the best appearance.
- 8. Install the first plank in the second row by inserting the long side tongue into the groove of the plank in the first row. This is best done with a low angle of the plank. Maintain light pressure into the side seam as you rotate the plank to the subfloor. Repeat the process with additional planks to complete each row. Very little force is required to seat the tongue into the groove. You should feel the tongue lock into the groove.
- 9. It is critical to keep the first two rows straight and square, as they are the "foundation" for the rest of the installation. Check for squareness and straightness often.
- 10. Continue installing planks and make sure to achieve a random appearance with end pieces of minimum 6" - 15cm. Check that all planks are fully engaged; if a slight gapping is found, the gap can be tapped together by using a tapping block and a scrap of flooring to cover the tapping block in order to avoid damages on the planks.
- 11. To fully engage the short end, apply light pressure and press down to engage the end joint. If the end is raised use a non-marking rubber mallet to lightly tap the end (tongue side) about 1" from the seam. **Do NOT** tap directly on the seam.
- 12. When fitting under door casings, if necessary, a flat pull bar may be used to assist in locking the planks.
- 13. When fitting around obstacles or into irregular spaces, planks can be cut easily and cleanly using a utility knife with a sharp blade. It is often beneficial to make a cardboard template of the area and transfer this pattern to the plank.
- 14. Protect all exposed edges of the flooring by installing wall molding and/or transition strips. Make sure that no plank will be secured in any way to the sub floor.
- 15. For wet areas such as bathrooms caulk the perimeter of the floor with a silicone caulk.
- 16. Protect the finished flooring from exposure to direct sunlight to reduce fading and thermal expansion.

COMPLETING THE JOB – ALL INSTALLATIONS

- **Sweep or vacuum floor.**
- **Clean the floor with proper hardwood floor cleaner.**
- **Install transition pieces -i.e. – thresholds, t-moldings, base boards and quarter round. Nail moldings to wall, not the floor.**
- **Inspect final floor for nicks and or minor gaps – fill with appropriate color wood putty.**
- **Unused material should be left with owner and stored in a dry place in case of future repairs are needed.**
- **Use plywood or hardboard when moving heavy appliances or furniture across floor.**

PREVENTATIVE MAINTENANCE

- Always protect floors from direct exposure of sunlight that can cause the wood or stain to change colors. Warranties do not cover damage from UV exposure. Recommended humidity levels are between 35% R.H. - 55% R.H.
- Protect floors when moving heavy objects to prevent permanent scratches and tears. The use of plywood and heavy cardboard are examples of protective barriers.
- Use appropriate wide floor protectors under tables, chairs, and any other heavy home furnishing to avoid permanent damage. As a rule, the heavier the object, the wider the floor protector.
- Walk-off mats should be used at all entrances to absorb soil and moisture. The use of appropriate mats will help avoid scratches and damages to the floor. If mats are placed directly on top of the hardwood floors, use proper indoor mats. Mats that can trap moisture underneath have potential to cause possible discoloration. Latex and rubber backings should not be used.
- Area rugs are recommended in high traffic and pivot areas. Avoid shoes with spiked or damaged heels. Also keep pets' paws and nails cleaned and trimmed.

FLOOR CARE AND MAINTENANCE

- Sweep or vacuum regularly since built-up grit can damage the surface of the wood. The vacuum head must be a brush or felt type. Be certain the wheels of the vacuum are clean and do not damage the finish. Do not use a vacuum with a beater bar head.

Remember, like any floor covering, our factory finished wood floors will show signs of wear over time, depending on the size and lifestyle of your family. By observing a few precautions and setting up a regular cleaning routine and maintenance program, you can expect years of beauty from your floor. The following are examples of the reasonable and necessary maintenance you are expected to perform. They are not intended to be an exclusive list.

- Remove spills promptly using a soft cloth and cleaning products recommended by the manufacturer.
- Mist a Neutral Ph hardwood floor cleaner to damp-mop your floor. Do not use hardwood floor cleaning machines or steam cleaners as this can severely damage the flooring and will void the warranties. See section on Improper Maintenance.
- Use the manufacturer's recommended Hardwood floor cleaners with a clean terry cloth mop. Always sweep or vacuum the floors prior to using wood floor cleaners. Do not allow excess cleaner to remain on the floors surface as this may permanently damage the wood fiber.
- **Important:** Do not use oil soaps, liquid or paste wax products or other household cleaners that contain citrus oils, lemon oil, tung oil, silicon, or ammonia since these warranties do not cover damage caused by non-recommended products. Use of these and other such products will harm the long-term performance of your floor and may also affect its recoat ability.
- Do not use 2 in 1 cleaners with polish that may contain acrylics or urethane polish to restore gloss – the use of these products will void the finish warranty and may produce unsatisfactory results when not applied properly.
- Keep pets' nails trimmed, and paws clean and free of dirt, gravel, grease, oil, and stains.
- Place protective felt pads beneath furniture legs and feet to reduce scratches and dents. Replace pads as needed.
- Use a dolly and protective sheets of plywood when moving heavy objects, furniture, or appliances.
- Make certain furniture casters are clean and operate properly (a minimum 1" wide vinyl surface where it comes in contact with wood is recommended). Clean wheels periodically to remove dirt and debris.
- Remove shoes with spiked or damaged heels before walking on floor.
- Exposure to the sun and its UV rays accelerates the oxidation and aging of wood. This can cause the stain and/or wood to fade and/or to change color. We recommend that you rearrange rugs and furniture periodically so the floor ages evenly. Exotic species such as Brazilian Cherry are more susceptible to color change during the aging process. These warranties do not cover damage from the sun and its UV rays.
- Use area rugs in high traffic areas and pivot points (e.g., stair landings, room entries, etc.), especially if you have a large family or indoor pets.
- Maintain the proper Relative Humidity in your home between 35% - 55%. The use of a humidifier during heating seasons may help reduce shrinkage of the wood due to low humidity.
- **Do not use tape to secure floor protection during construction or renovation.** Use ram board or similar to protect the floor.